

Luxafor Active Noise Cancelling Bluetooth Headphones



User Manual

Luxafor ANC Bluetooth Headphones Package Contents

1x Headphones
1x Detachable Aux Cable
1x ¼ inch Stereo-plug Adapter
1x Dual-plug Adapter (for Aircraft)
1x USB Charging Cable
1x Small Mesh Bag
1x Hard Shell Case
1x Gift Box

Product Specifications

Bluetooth version: 4.1 Bluetooth

Bluetooth operating range: ≥10 m

Chipset: CSR8645 w/apt-X

Noise cancellation rate: 85%

Speakers: 40mm Neodymium

Audio impedance: 32Ohm

Connection: 3.5 mm jack

Charging:

With a standard micro USB data cable


Charging time: about 3.0 hours

Battery Type: Li-Polymer

Working time: 12 h - 30 h depending on working mode¹


Overview

Left Side



1. USB Socket (For Charging)
2. Volume - / Previous Song (Only for Bluetooth)
3. Multifunction Button (MFB) / Switch ON/OFF, Pairing, Make/Answer/End/Reject Call
4. Volume + / Next song (Only for Bluetooth)
5. Microphone
6. 3.5mm Audio Jack
7. Bluetooth LED Indicator

Right Side



8. Volume + / - Knob (For Bluetooth, Noise-Cancelling or Wired)⁵
9. Noise-Canceling ON/OFF Button
10. Noise-Cancelling LED Indicator

Adjusting the Headband

In order to achieve maximum comfort and noise cancellation, the headband should be adjusted to properly fit your head with the ear cups sitting comfortably over your ears.

Charging Instructions

1. Prior to use, charge your headphone unit by connecting the included charging cable into a USB power outlet² such as USB charger, and plug the other end into the headphone's micro USB charging port.
2. The LED indicator will light up red showing that the unit is being charged. When charging is complete, the red LED indicator will turn off.

Getting started

1. Once your Bluetooth Headphones have been fully charged, pair them with a Bluetooth-enabled mobile phone prior to first use.

Pairing Your Headphones

The headphones work with Bluetooth-enabled phones. Prior to using and pairing your headphones for the first time, please check to make sure your mobile phone is Bluetooth-enabled.

The headphone pairing procedure may vary depending on the settings of your mobile phone. Please contact the manufacturer of your mobile phone or its agent for further information.

1. Press and hold the MFB for about 4 seconds until the Bluetooth LED indicator flashes and alternates between green and red. The headphones will now enter into pairing mode.
2. Enable searching of nearby Bluetooth devices using the Bluetooth menu on your device.
3. Once the "LUX ANC" is found, you can now connect and pair. If your device prompts you for a password, please use "0000" - For more details, please refer to your device's user manual.

4. When pairing is successful, the Bluetooth LED indicator will flash green every 4 seconds. If pairing is unsuccessful, please turn off the LUX ANC headphones and repeat the pairing steps.

After initial pairing is established, the headphones will automatically reconnect to the last paired device upon turning ON.

Active Noise Cancelling Mode

- Adjust the volume on the headphones.
- To power ON the Noise- Canceling function, set the ON/OFF switch to ON. The Noise -Cancelling LED indicator will light up blue.³
- When the batteries are running low, the Noise Cancelling LED indicator will become dim.
- Once the battery is fully drained, the Active Noise-Canceling feature will turn off, but the audio signal from the music player will continue to transmit.
- In quiet environments where noise cancelation is not required, the Luxafor ANC Headphones can also be used as conventional headphones, without the use of batteries.
- When not in use, turn OFF the POWER to extend battery life.

Bluetooth Functions

Turning the Headphones ON/OFF

1. Power ON your headphones: Press and hold the Multifunction Button (MFB) for about 4 seconds until the Bluetooth LED indicator light starts flashing green/red rapidly with an ascending sound.
2. Power OFF your headphones: Press and hold the MFB for about 5 - 6 seconds until the Bluetooth LED indicator light turns solid red with a descending sound.

Getting Started with your Headphones

To use your Stereo Bluetooth Headphones, please follow the steps below:

1. Ensure your Bluetooth Headphone is fully charged.
2. Pair your charged Bluetooth Headphone with a Bluetooth-enabled mobile phone prior to first use. Please fully charge your new headphones before first use.

Call-related Functions

| | |
|--|--|
| Answer a call | Press MFB once to answer |
| End a call | Press MFB again to end |
| Ignore a call | Hold MFB for 3 seconds |
| Last number re-dialing from headphones | Press MFB twice in standby status |
| Swap calls | Press MFB for 3 seconds while speaking |

Music-related Functions

| | |
|--------------------|---|
| Play/Pause Music | Press down the MFB Button (▶) once to start playing music and press it again to pause music |
| Next/Previous Song | Press down the Music/Volume Control button towards the Forward icon (▶▶) to play the next song. To play the previous song, slide and release the Music/Volume Control button |

| | |
|--|--------------------------------|
| | towards the backward icon (⏮). |
|--|--------------------------------|

Voice Dialing from your Headphones

If your mobile phone is equipped with a voice dialing function, press and hold the MFB button and say the voice tag according to the phone's command functions.

You must record the voice tag (the person's name) into your mobile phone prior to using the voice dialing function on the headphone. Please refer to your mobile phones' user guide.

Using the 3.5mm Audio Cable

3.5 mm audio cable is included for use with multimedia devices that do not have Bluetooth capabilities. You may also use the audio cable if the headphones are not charged properly.

Safety instructions

- Always turn down the volume control before plugging the headphones into a sound source.
- Do not use these headphones where vehicular traffic is present, or in any other activity where a failure to hear surrounding sounds could be dangerous.
- Maintenance and service operations are only to be carried out by authorized dealers. Damage caused by manual modifications of the product is not subject to warranty.
- If this product is used for other purposes than originally intended, the product may suffer damage and will void the warranty.
- Long-term exposure to loud music may cause hearing damage. It is best to avoid extreme volume when using these headphones, especially for extended periods.
- Keep batteries out of the reach of children.

Luxafor ANC Headphones' Battery Duration

The battery duration for Luxafor ANC Headphones varies depending on multiple variables, including the functionality and if used continuously or infrequently.

The battery working time on continuous use:

- **15 hours:** Bluetooth only;
- **30 hours:** Noise-Canceling only;
- **12 hours:** Bluetooth + Noise-Canceling.

Additional Remarks

¹ See “Luxafor ANC Headphones' Battery Duration” for detailed working hours variation.

² Do not use computer USB ports to charge Luxafor ANC Headphones, as this can result in a much slower and less energy-efficient charging process.

³ After you turn ON the power, you might hear a slight hissing noise. This is a normal function and will cease after a few seconds.

⁴ You are able to use both Noise-Cancelling & Bluetooth Function simultaneously.

You may notice 2 types of volume controls on the headphones. The headphones are a multifunctional unit. They can be used as a regular wired, Active Noise -Canceling, or Bluetooth headphones. The right side volume wheel (Volume A) works for all functions - the left side volume buttons (Volume B) only work for BT headphone functionality. (See “Overview” section of this manual).

⁵Adjusting Volume B:

When you are on the phone or listening to music, push the volume button (8) or long press the button (2) /(4) repeatedly until you reach the desired volume level.

Troubleshooting Steps for Known Issues

If you are unable to connect your headphones to your mobile phone, please try the following:

1. Ensure your headphones are turned OFF and properly charged.
2. Ensure the headphones are properly paired with your mobile phone.
3. Ensure the headphones are within a 10-meter range of your paired Bluetooth device and that there are no obstructions, such as walls or other electronic devices in between.
4. Ensure your mobile phone's Bluetooth feature is activated. Please refer to your mobile phone user guide for specific instructions.
5. To reset certain functions of the headphones you can simply plug-in to recharge and then disconnect.

If you were unable to resolve the issues you are having with these troubleshooting steps, and you feel your product is still not working properly, please don't hesitate to contact us at support@luxafor.com or call +371 27755544.

Send us a full report of the issue, explaining the details of the situation, when the issue first occurred and if the issue persists throughout the troubleshooting process. Don't forget to mention the OS you're using and pictures/ videos to better explain the situation.

Safety Instructions

- Always turn down the volume control before plugging the headphones into a sound source.
- Do not use these headphones where vehicular traffic is present, or in any other activity where a failure to hear surrounding sounds could be dangerous.
- Maintenance and service operations are only to be carried out by authorized dealers. Damage caused by manual modifications of the product is not subject to warranty.
- If this product is used for other purposes than originally intended, the product may suffer damage and will void the warranty.
- Long-term exposure to loud music may cause hearing damage. It is best to avoid extreme volume when using these headphones, especially for extended periods.
- Keep batteries out of the reach of children.